

Urban SD Foot Pump- Installation Guidelines

Model: URS-812-ECM-PU*H

The Urban Super Duty Foot Pump is a heavy duty, foot operated air pump suitable for indoor or outdoor applications. It must be anchored to a concrete surface to ensure security and provide optimal performance. Anchoring the pump to an asphalt surface may compromise the security of the pump, and must be done with the aid of an appropriate asphalt adhesive.

Minimum Concrete Requirements

Recommended Pad Size: 12" x 12" (minimum 10" x 10")

Thickness: 4 1/2" (minimum 4")

For new concrete, allow up to ten days for cure before installing anchors

Tools Required

1/2" Masonry Drill Bit

Hammer Drill

Hammer

Ratchet with Extension or Drill/Driver

3/4" Deep Socket

Caulking gun (optional for asphalt installations)

Asphalt Epoxy (optional for asphalt installations)

4" x 1/2" Concrete Wedge Anchors (quantity 4)

Anchoring the Pump

The assembly can be anchored using standard concrete wedge anchors (provided if purchased), available at most home improvement stores.

Using a 1/2" masonry drill bit, drill holes in the concrete to a depth of approximately 3". Blow the concrete dust from the hole using compressed air (do not breathe the dust)

Place the anchors into the holes and hammer them down until they bottom out in the hole.

Note: push the anchors through the holes of the pump base. Setting the anchors in the concrete prior positioning the pump will make aligning the holes difficult.

Tighten each anchor until the anchors set into the concrete. Note that during tightening, the anchor will lift out of the concrete a little; this is normal.

If desired, the tops of the anchors may be cut off for a cleaner appearance.

When anchoring to an asphalt surface determine what type of material is directly below the asphalt.


If concrete, anchor as above using 5 1/2" wedge anchors to ensure the anchors reach the concrete.

If no concrete is present, the anchors must be set using an appropriate asphalt adhesive. Urban Racks recommends ITW A7 Epoxy adhesive or equivalent two part epoxy for concrete or asphalt applications.


Following the directions above and prior to putting the anchors into the holes, add epoxy adhesive into each hole to fill approximately half way.

Install the anchors as above but do not fully tighten the nuts until the epoxy has set for 30-60 minutes. The nuts can be fully tightened after 24 hours.

TOP VIEW



Anchoring Detail



URBAN RACKS

INNOVATIVE | BICYCLE PARKING

1-888-717-8881 sales@urbanracks.com

For more product and company information,
please visit us at www.urbanracks.com